

Identifying your iPad model

Your iPad Model number can be found on the back of your iPad.



Supported iPad Models:

iPad Pro 11" (4th generation – 2022)

Models: **A2759, A2435, A2761, A2762**

iPad Pro 12.9" (6th generation - 2022)

Models: **A2436, A2764, A2437, A2766**

iPad Pro 11" (3rd generation – 2021)

Models: **A2301, A2377, A2459, A2460**

iPad Pro 12.9" (5th generation - 2021)

Models: **A2378, A2461, A2462, A2461**

iPad Pro 11" (2nd generation – 2020)

Models: **A2228, A2068, A2230, A2231**

iPad Pro 12.9" (4th generation - 2020)

Models: **A2229, A2069, A2232, A2233**

iPad Pro 11" (2018)

Models: **A1980, A2013, A1934, A1979**

iPad Pro 12.9" (3rd generation - 2018)

Models: **A1876, A2014, A1983, A1895**

iPad Pro 12.9" (2nd generation - 2017)

Models: **A1670, A1671**

iPad Pro 10.5"

Models: **A1701, A1709**

iPad Pro 9.7"

Models: **A1673, A1674, A1675**

iPad (10th generation - 2022)

Models: **A2696, A2757, A2777**

iPad (9th generation - 2021)

Models: **A2602, A2603, A2604, A2605**

iPad (8th generation - 2020)

Models: **A2270, A2428, A2429, A2430**

iPad (7th generation - 2020)

Models: **A2197, A2200, A2198, A2199**

iPad Air 4 (2020)

Models: **A2316, A2324, A2072, A2325**

iPad Air 3 (2019)

Models: **A2152, A2123, A2153, A2154**

iPad (6th generation - 2018)

Models: **A1893, A1954**

iPad (5th generation - 2017)

Models: **A1822, A1823**

iPad Air 2

Models: **A1566, A1567**